

In the case of a spill **YOU** are responsible for 3Rs:

1. **REACT** to the spill
2. **REPORT** the spill to MdTA Police, the vehicle processing company and your trucking company.
3. **RESPOND** to the spill and begin clean up.



Maryland Port Administration
Safety, Environmental, and Risk
Management Department

2700 Broening Hwy
Baltimore, MD 21222
Phone: 410-633-1145
Fax: 410-285-0921

www.marylandports.com
www.mde.state.md.us



Maryland Port Administration Oil Spill Prevention Control and Countermeasure



In the case of an oil spill of ANY size,
please contact MdTA Police

Port Emergency Contacts

24-Hour Spill Reporting:

MDE 1-866-633-4686

NRC 1-800-424-8802

| | |
|------------------------|---------------------|
| MdTA Police | 410-633-1092 |
| Operations | 410-633-1077 |
| Safety & Environmental | 410-633-1145 |
| Security | 410-285-2521 |

How To Control An Oil Spill

1. Stop the flow
 - a. This may involve plugging a hole, shutting a valve, or kinking a hose.
2. Notify MdTA Police, the vehicle processing company and your trucking company, if applicable.
3. Contain the spill
 - a. Prevent the spill from migrating
 - b. Use absorbent booms/pillows from spill response kit
 - c. If you can not contain the spill block off any nearby storm drains to prevent spills from entering
4. Your trucking company/owner is responsible for all spill clean-up and reporting.
 - a. Your company may need to hire a clean-up company.
 - b. All spills must be reported to:
 - i. MDE 1-866-633-4686
 - ii. NRC 1-800-424-8802



Spill Kit Locations

Spill Kits are located by the security guard gate.

Truck spill kits can be found at:

www.newpig.com

www.seallarscompany.com

www.northernsafety.com

Notify security if you need to use its spill kit or if you need speedy-dri and assistance with cleanup procedures.



A Spill Kit Contains:

- Absorbent Pads
- Absorbent Socs/Booms
- Absorbent Pillows
- Emergency Response Handbook
- Nitrile Gloves
- Disposable Bags
- Pair of Goggles

How To Properly Cleanup an Oil Spill

1. Contain spill and block off any nearby storm drains.
2. Apply speedy-dri and sweep back and forth over spill until it is fully absorbed.
 - a. Apply speedy-dri multiple times if necessary.
3. Speedy-dri needs to be picked up immediately after applying.
4. Sweep/shovel speedy-dri into trash bags.
5. Place any other absorbent booms, pad, or pillows used in trash bags.
6. Tie trash bags and dispose of properly offsite.

